

**Schurter**

**SCHURTE**  
ELECTRONIC COMPONE

## CPS19-LA00A10-SNCCWTF-AIORWVAR-W1004-S

Tau Wae:	CPS19-LA00A10-SNCCWTF-AIORWVAR-W1004-S
Kaihanga / Waitohu:	Schurter
Whakaahuatanga hua	SWITCH PUSHBUTTON SPST 100MA 42V
Ngā Rauemi:	CPS19-LA00A10-SNCCWTF-AIORWVAR-W1004-S.pdf
RoHs Tūnga	Whakahaerehia te kore utu / RoHS
Waehe Stock	5648 pcs stock
Tuhinga mai i	Hong Kong
Te Ara Tuhi	DHL/Fedex/TNT/UPS/EMS

TONO MO TE WHAKAHUA

Ko te whakaahua he tohu. Tirohia nga korero mo nga taipitopito hua.

### Ngā whakaaturanga o CPS19-LA00A10-SNCCWTF-AIORWVAR-W1004-S

TAU WAE	CPS19-LA00A10-SNCCWTF-AIORWVAR-W1004-S
KAIHANGA	Schurter
WHAKAAHUATANGA	SWITCH PUSHBUTTON SPST 100MA 42V
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Whakahaerehia te kore utu / RoHS
HE RAHINGA KEI TE WĀTEA	5648 pcs
PEPA RARAUNGA	CPS19-LA00A10-SNCCWTF-AIORWVAR-W1004-S.pdf
WHAKAAETANGA NGAOHIKO - DC	60V
WHAKAAETANGA NGAOHIKO - AC	42V
MOMO	Capacitive, Illuminated
KĀHUA WHAKAMUTUNGA	Wire Leads
WHAKAWHITI MAHINGA	Off-On
RAUPAPA	CPS
PIHANGA WHAKAPAE PAEPAE	Circular - 19.10mm Dia
PACKAGING	Bulk
TAE MAHI	-40°C ~ 60°C
MOMO TAE	Panel Mount, Front
TAUMATA WHAKAARO MOE (MSL)	1 (Unlimited)
TE MAHI MOMO	-
WHAKAHAERE TOKO WHAKAHAERE / ROHS TŪNGA	Lead free / RoHS Compliant
TIAKI INGOA	IP67 - Dust Tight, Waterproof
WHAKAKAMAHI WHAKAKUKU (NOMINAL)	5 ~ 28 VDC
MOMO WHAKAMARAMA, TAE	LED, Red/White
NGĀ ĀHUATANGA	Ceramic Actuator, Finger Guide, D Symbol
TE ORANGA RAWA	-
WHAKAAHUATANGA TAIPITOPITO	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
WHAKATAURANGA ONAMATA	100mA (AC/DC)
TAE - KAIHOAHOA / KAPORO	Clear (White Filter/Diffuser)
TAKAHANGA	SPST
MOMO KAIHOKO	Round, Button, Flush

### Ngā tūtohu e hāngai ana

Schurter CPS19-LA00A10-SNCCWTF-AIORWVAR-W1004-S	CPS19-LA00A10-SNCCWTF-AIORWVAR-W1004-S Kaiwhiwhi	CPS19-LA00A10-SNCCWTF-AIORWVAR-W1004-S Kaiwhakarato
CPS19-LA00A10-SNCCWTF-AIORWVAR-W1004-S Utu	CPS19-LA00A10-SNCCWTF-AIORWVAR-W1004-S Pikitia	CPS19-LA00A10-SNCCWTF-AIORWVAR-W1004-S Whakaahua
CPS19-LA00A10-SNCCWTF-AIORWVAR-W1004-S PDF Datasheet	CPS19-LA00A10-SNCCWTF-AIORWVAR-W1004-S Download Datasheet	Tuhinga CPS19-LA00A10-SNCCWTF-AIORWVAR-W1004-S
CPS19-LA00A10-SNCCWTF-AIORWVAR-W1004-S Stock	Hokona CPS19-LA00A10-SNCCWTF-AIORWVAR-W1004-S	Hokona Schurter CPS19-LA00A10-SNCCWTF-AIORWVAR-W1004-S
Schurter CPS19-LA00A10-SNCCWTF-AIORWVAR-W1004-S	Schurter Kaiwhakarato	Schurter Kaiwhiwhi
Schurter CPS19-LA00A10-SNCCWTF-AIORWVAR-W1004-S	Schurter Inc. CPS19-LA00A10-SNCCWTF-AIORWVAR-W1004-S	

### Ngā Hua e hāngai ana

<p><b>CPS19-LA00A10-SNCCWTF-AIORWVAR-W0000-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5560 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS19-LA00A10-SNCCWTF-AIORWVAR-W1009-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5427 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p><b>CPS19-LA00A10-SNCCWTF-AIORWVAR-W1003-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4887 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS19-LA00A10-SNCCWTF-AIORWVAR-W1006-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 6640 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p><b>CPS19-LA00A10-SNCCWTF-AIORWVAR-W1005-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 3350 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS19-LA00A10-SNCCWTF-AIORWVAR-W1001-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 3147 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p><b>CPS19-LA00A10-SNCCWTF-AIORWVAR-W1010-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4122 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS19-LA00A10-SNCCWTF-AIORWVAR-W1007-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 4266 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p><b>CPS19-LA00A10-SNCCWTF-AIORWVAR-W1002-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5075 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS19-LA00A10-SNCCWTF-AIORWVAR-W1008-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 7054 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>
<p><b>CPS19-LA00A10-SNCCWTF-AIORMVAR-W1077-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 2921 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>	<p><b>CPS19-LA00A10-SNCCWTF-AIORMVAR-W1076-S</b> Kaihanga: Schurter Whakaahuatanga: SWITCH PUSHBUTTON SPST 100MA 42V I roto i te taonga: 5513 pcs</p> <p style="text-align: center; background-color: #ccc; padding: 5px; font-weight: bold;">RFQ</p>